

FIRMWARE UPDATE EM-10AHD




3010003010_62-H3010.zip



- CZ-SK-ENG
- CZ-PL-ENG
- CZ-SI-ENG
- CZ-HU-ENG



COPY




System

| | | | |
|------------------|----|---------------|----|
| Language | << | English | >> |
| Date Type | << | YY-MM-DD | >> |
| Date | << | 2020-12-09 | >> |
| Time | << | 00:00 | >> |
| SD Format | << | Format | >> |
| About | << | Factory reset | >> |
| Software Version | << | ABC1234567890 | >> |



System

| | | | |
|------------------|----|-----------------|----|
| Language | << | English | >> |
| Date Type | << | YY-MM-DD | >> |
| Date | << | 2020-12-09 | >> |
| Time | << | 00:00 | >> |
| SD Format | << | Format | >> |
| About | << | Firmware update | >> |
| Software Version | << | ABC1234567890 | >> |



System

| | | | |
|------------------|----|-----------------|----|
| Language | << | English | >> |
| Date Type | << | YY-MM-DD | >> |
| Date | << | 20-12-09 | >> |
| Time | << | 00:00 | >> |
| SD Format | << | Format | >> |
| About | << | Firmware update | >> |
| Software Version | << | ABC1234567890 | >> |

Firmware update
YES NO



Firmware updating. Don't power off